

***Thank you for purchasing SacCityCorvette's Warning Star!***

***C5/C6 Installation instructions.***

While looking at the back of your Corvette's right-side taillights, using a T-15 Torx Bit remove the inner taillight (closest to the license plate). With the light removed, reach in and unplug connector from Third Brake Light. We recommend you look at the installed picture on [saccitycorvette.com](http://saccitycorvette.com) to see how to unplug the connector and install the Warning Star. Clean the area below the third brake light where you will be sticking the Warning Star after its all plugged in. We recommend peeling the back off the sticky tape before you plug it in, because you will only have one hand in the brake light hole to do the install. Plug the Warning Star on to the wiring harness connector first and then on to the Third Brake light. After the Warning Star is plugged in, stick the module to the body below the Third Brake light as shown in picture. Test operation and install taillight. Any questions please text 916 968-4451 or email [Sales@saccitcorvette.com](mailto:Sales@saccitcorvette.com)

**Now you're ready to - Give Em the middle blinker!**

Thank you,  
SacCityCorvette

Rev. 12/20/2021



